



# AV-OL-FL864-12-R & AV-OL-FL864-UM-R

FAA L-864 Medium Intensity Obstruction Light Universal DC & Universal AC Models

### **INSTALLATION & SERVICE MANUAL**



# **Table of Contents**

Introduction	4
Technology	5
AV-OL-FL864-12-R & AV-OL-FL864-UM-R Medium Intensity Obstruction Light	6
Technical Drawings Specifications	
Safety Information	9
Unpacking, Installation, Wiring & Setup	10
Unpacking	.10 11 13 13 13 14 14 14
Optional IR Remote Control	16
Avlite IR Controller / Universal Remote CompatibilityIR Controller Functions	

Optional GPS Synchronization	19
Operating Principle	19
Light Activation	19
Daylight Operation	19
Dark Operation	20
GPS Power Demand	20
Optional GSM Monitoring & Control	21
Troubleshooting	21
Lantern Status	22
Certification	23
Avlite Light Warranty V1.2	24
Other Avlite Products Available	28

Version No.	Description	Date	Author
1.0	Manual launch	March 2015	W. Evans
1.1	Spec table update March 2015 J. D		J. Dore
1.2	Warranty update	March 2015	W. Evans
1.3	Update installation & wiring	June 2015	W. Evans
1.4	Spec table update	Dec 2016	W. Evans
1.5	Update for FAA AC150_5345_43H	May 2017	J. Ohle
1.6	Update Pg 22	Jan 2018	J. Ohle



# Introduction

Congratulations! By choosing to purchase an Avlite light, you have become the owner of one of the most advanced LED obstruction lights in the world.

Avlite Systems draws on more than 25 years' experience in the design and manufacture of navigation aids, and particular care has been taken to ensure your light gives years of trouble free service.

As a commitment to producing the highest quality products for our customers, Avlite has been independently certified as complying with the requirements of ISO 9001:2015 quality management system.

By taking a few moments to browse through this booklet, you will become familiar with the versatility of your light, and be able to maximize its operating function.

Please remember to complete the Avlite warranty registration card accompanying your light.



# **Technology**

Avlite Systems is a world-class solar lighting systems manufacturer with a proven reputation for rapid, innovative, and agile technology solutions designed specifically for defence, government, civil and humanitarian aid operations in the most remote, toughest environments.

### **Electronics**

Avlite employs leading in-house electronic engineers in the design and development of software and related circuitry. All individual electronic components are sourced directly by Avlite procurement staff ensuring that only the highest quality components are used in our products.

### **LED Technology**

All Avlite lights use the latest advancements in LED (Light Emitting Diode) technology as a light source.

The major advantage of LED's over traditional light sources is well established in that they typically have an operational life in excess of 100,000 hours, resulting in substantial savings to maintenance and servicing costs.

#### **Precision Construction**

Commitment to investing in the design and construction of injection-moulded parts including optic lenses, light bases and a range of other components ensures that all Avlite products are of a consistent and superior quality.

# **Optical Performance**

Avlite manufactures a range of aviation LED lenses moulded from multi-cavity dies. The company has superior in-house lens manufacturing capabilities to support outstanding optical performance.

### **Award-winning, Patented Technology**

Several United States and Australian patent registrations are held on Avlite's range of innovative designs, with other regional patents pending in Canada, United Kingdom and Europe.



# AV-OL-FL864-12-R & AV-OL-FL864-UM-R Medium Intensity Obstruction Light


This Avlite medium intensity LED obstruction light is certified to the FAA L-864 Medium Intensity Obstruction Lighting advisory circular 150/5345-43. The light is used to mark obstacles such as telecommunication and utility towers, wind turbines, cranes, buildings and other tall structures.


Avlite's LED obstruction lights offer an ultra-bright, energy efficient and cost effective lighting solution. The light fixture is available in two configurations, universal DC (12–48VDC) or universal AC (110–240VAC).

The light fixture incorporates internal diagnostic checking and an alarm contact for remote monitoring. The alarm relay is energized in normal operation and is released if there is an LED or power fault.

# **Technical Drawings**









# Specifications \* FAA L-864 MIOL

	12-48 VDC	110-240 VAC
Light Characteristics		
Available colours	Red as standard. Other colours available on request	Red as standard. Other colours available on request
Effective Intensity (cd)†	2000cd ± 25%	2000cd ± 25%
Horizontal Output (degrees)	360	360
Vertical Divergence (degrees)	3°	3°
Available Flash Characteristics	0.2s ON, 1.8s OFF – 10% duty cycle	0.2s ON, 1.8s OFF - 10% duty cycle
Electrical Characteristics		
Operating Voltage	12 – 48 VDC	110 - 240 VAC 50/60Hz
Power (Average Flashing)	5W	Pmax: 5W, Smax: 7.6VA
Power (Peak)	60W	Pmax: 60W, Smax 80VA
Circuit Protection	Integrated	Integrated
Temperature Range	-40 to 55°C	-40 to 55°C
Physical Characteristics		
Body Material	7-stage powder-coated aluminium	7-stage powder-coated aluminium
Lens Material	Impact modified UV stabilized acrylic	Impact modified UV stabilized acrylic
Lens Diameter (mm/inches)	171 / 6¾	171 / 6¾
Lens Design	Multi LED Optic	Multi LED Optic
Mounting	200mm bolt pattern	200mm bolt pattern
Height (mm/inches)	151 / 6	151 / 6
Width (mm/inches)	230 / 9	230 / 9
Depth (mm/inches)	230 / 9	230 / 9
Mass (kg/lbs)	5.5 / 121/4	5.8 / 123/4
Product Life Expectancy	12 years plus	12 years plus
Environmental Factors		
Humidity	0 to 100%, MIL-STD-810F	0 to 100%, MIL-STD-810F
lcing	3.41kg per square cm / 48.5lbs per square inch	3.41kg per square cm / 48.5lbs per square inch
Wind Speed	Up to 240kph / 150mph	Up to 240kph / 150mph
Certifications		
CE	EN61000-6-3:2007 EN61000-6-1:2007	EN61000-6-3:2007 EN61000-6-1:2007
Quality Assurance	ISO9001:2015	ISO9001:2015
FAA, DGAC.	L-864 Medium Intensity Obstruction Light (Qualified by Intertek)	L-864 Medium Intensity Obstruction Light (Qualified by Intertek)
Waterproof	IP68	IP68
Intellectual Property		
Trademarks	AVLITE® is a registered trademark of Avlite Systems	AVLITE® is a registered trademark of Avlite System
Warranty *	5 year warranty	5 year warranty
Options Available	Variety of solar/battery configurations     GSM Cell-Phone Monitoring     GPS Synchronisation     RS422/485 communications port	GSM Cell-Phone Monitoring     GPS Synchronisation     RS422/485 communications port



- Specifications subject to change or variation without notice
   \* Subject to standard terms and conditions
   † Intensity setting subject to solar availability

# **Safety Information**

- Install the light in compliance with the effective local electrical code(s).
- Mains power should always be disconnected when work is being done in close proximity to electrical fittings, and electrical work should only be done by a licensed electrician.
- Operate the light only within the indicated electrical ratings and product usage instructions.
- To ensure that the light and peripheral equipment function safely and correctly, use cable in compliance with the effective local electrical code.
- Do not stare at the LED or shine the LED into your eyes or those of another person.
- Do dispose of the product according to the local laws and regulations for your region, for example, at a recycling center that accepts electronic devices.



# **Unpacking, Installation, Wiring & Setup**

# **Unpacking**

Unpack all hardware and inspect for damage. If there is any damage, please contact your Avlite Office.

Retain original packing material for possible future use in shipping.

# **Installation & Wiring**

Before proceeding with installation or service, make sure the following conditions are met:


- Ensure the tower or mast is grounded (NO RF HAZARD)
- Check the mast lighting circuit is not faulty
- Ensure power lines are not 'live' (NO ELECTRICAL HAZARD)
- Avoid touching live circuits!
- Avoid touching any component or any part of the circuitry while the unit is operating.
   Do not change components or make adjustments inside the unit with power on.
- The obstruction light is manufactured with an input power cable of length defined at the time of order. One end of the input power cable is pre-terminated at the light fixture.

Connect the provided input power cable to the corresponding power source in accordance with figure 1 for AC installations and figure 2 for DC installations.


# **AC Wiring Configuration**

#### **External:**

	Australia/ Europe/ UK	USA/ Canada
Active/Live (L1)	Brown	Black
Neutral (L2)	Blue	White
Earth	Green/Yellow	Green








No.	Connector	Signal
1	POWER	L1
2	POWER	L2
3	POWER	GND
4	ALARM	COMM
5	ALARM	NO
6	ALARM	NC
7	RS232	GND
8	RS232	RxD
9	RS232	TxD
10	RS422	GND
11	RS422	-VE (Rx)
12	RS422	+VE (Rx)
13	RS422	-VE (Tx)
14	RS422	+VE (Tx)
15	IO-1	3V3
16	IO-1	OUT-1
17	IO-1	OV
18	IO-1	IN-1
19	IO-1	OV




# **DC Wiring Configuration**

### External:







					_	
п	-1	$\alpha$	H	re	$\sim$	/

No.	Connector	Signal
1	+VIN	+VDC
2	-VIN	-VDC
3	ALARM	COMM
4	ALARM	NO
5	ALARM	NC
6	RS232	GND
7	RS232	RxD
8	RS232	TxD
9	RS422	GND
10	RS422	-VE (Rx)
11	RS422	+VE (Rx)
12	RS422	-VE (Tx)
13	RS422	+VE (Tx)
14	IO-1	3V3
15	IO-1	OUT-1
16	IO-1	OV
17	IO-1	IN-1
18	IO-1	OV

# Power Supply Design Considerations

Avlite's medium intensity obstruction lights are designed to operate over a wide operational voltage range and thus the average power consumption will vary accordingly.

There is a vast array of power sources that can be utilized for Avlite's medium intensity obstruction lights. However, the vast majority of customer power supplies comprise of either Photovoltaic Power or AC Utility and as such this bulletin will focus on these types and how they apply to Avlite's FAA L864 Medium Intensity Obstruction Lights.

Contact Avlite for advice when designing your power supply.

### (1) PV Power Systems

These systems generally comprise of a 1 or more PV panels, a solar regulator and storage battery. Batteries such as SLAs are very tolerant of fast switch high peak currents as they electrically behave like large smoothing capacitors, solar sizing depends on a number of factors. For Avlite obstruction lights, pay particular attention to average power consumption and power cable sizing.

### (2) Alternating Current (AC) Utility Power

In their simplest form, these systems comprise an AC/DC power supply converter. Unlike PV Power Systems, AC/DC Power Supplies are limited to their internal storage capacity and as such are not able to maintain voltage regulation to fast switch currents.

As such a lantern's peak current must be determined when selecting an AC/DC power supply. For Avlite's Obstruction Lights, the peak current can be determined by using the following equation:

Peak current (A) = Peak Power (W)) / (Supply Voltage (Vdc) Using this method, the peak current for the Avlite FL864 Obstruction Light: Peak Current (A) = 60 / 12 = 5 A

As an AC/DC power supply has minimal storage capacity the selected power supply must be capable of delivering the lights peak current for all conditions. Other considerations such as de-rating the AC/DC power supply due to environment and usage.



Peak Power is the maximum power rating of a light. In an instant of time, this is the maximum power the light will consume. It is determined when all a light's features are on and the LEDs intensity is at 100%.



### **Operation & Setup**

When powered up, the light will constantly check day/night status using its internal ambient light sensor. The ambient light sensor averages its measurement for 30 seconds.

**FAA:** By default, the lights turn ON when the ambient light decreases to not less than 35 foot-candles (367.7 lux) and turn OFF when the ambient light increases to not more than 60 foot-candles (645.8 lux). These limits can be factory adjusted, if required.

# **Intensity Setting**

The fixture will be supplied with a FAA compliant optic.

The obstruction light will be pre-set to the intensity setting required to produce a FAA compliant photometric profile. The intensity is pre-set in the factory and does not need to be set by the user.

### **Alarm Relay Output**

In normal operation, the relay is energized

- Terminal contacts COMM and NC of the relay are electrically closed
- Terminal contacts COMM and NO of the relay are electrically open

Whenever the LED is not lit due to a power failure and/or a LED failure the relay will not be energized.

- Terminal contacts COMM and NO of the relay are electrically closed
- Terminal contacts COMM and NC of the relay are electrically open

The alarm relay comes configured as follows:

Relay normal operation (default, as described above)

The following alarm relay configurations are available as a special order. These must be specified at the time of order:

- Relay inverse operation (inverse functionality of the normal operation, used to conserve power)
- Relay disable (in case the relay is not required, used to conserve power)



The alarm relay is intended for low voltage (SELV) connection only. NOT FOR MAINS CONNECTION

#### **Led Fault**

In the event of a singular LED fault, either open circuit or closed circuit across the LED, the light unit will turn off all LED's and actuate the Fault Relay.

### RS232 and RS422/485 Communication (Optional)

The Obstruction Light offers a RS232 and a R2422/485 interface.

**RS232** Typical 3 pin TxD, RxD and GND arrangement

**RS422/485** Typical 4 pin arrangement with Termination selection and Duplex/Simplex selection. For location details please refer to Figure 1 & 2.

Duplex		
SW3		
S1	S2	
OFF	OFF	Simplex operation
ON	ON	Duplex operation

Termination				
SW4				
S1	S2			
OFF	OFF	No termination		
ON	ON	120 Ohm termination		

Please contact Avlite for further details.



# **Optional IR Remote Control**

The IR remote is used to communicate with Avlite lighting products that have an IR sensor fitted. The remote control is used for the following functions:

- Operational Mode: dusk-to-dawn, standby or always-on.
- Ambient Light Thresholds: read the current light thresholds, configure new ambient light thresholds.
- · Perform a battery health check.

On receiving a valid key signal from the IR Remote, the light will flash once. The user should wait until the light responds to each keypress before pressing another key. If there is no response to the keypress after 3 seconds, it has not been detected by the light and the key can be pressed again.

If an invalid key is detected, the light will flash quickly 5 times. In this case, the command will have to be restarted.



# **Avlite IR Controller / Universal Remote Compatibility**

If you lose your Avlite IR Controller, the following Universal Remote Controller has been tested for compatibility: RCA Type RCR312WR programmed for Phillips TV Type Code 10054

Avlite Key	Universal Remote Key
T	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
R	Channel+
L	Mute
FC	Volume+
1	Volume-
В	Channel-

#### **IR Controller Functions**

#### **Test Mode / Configure**



Pressing the T/C button for up to 5 seconds places the light in Test Mode. The light will flash once in response to the T/C button being pressed and then turn off.

#### **Normal Operation**

The light will return to normal operation once it has not detected a valid key press for 30 seconds. The light will flash once to indicate it is returning to normal operation.


#### Read

Pressing the Read followed by one of the configuration keys shall cause the light to flash the configured value.

#### **Example Key Sequences:**













The light flashes the Operational Mode. Modes are as follows:

1 flash = Always-On 2 flashes = Standby

3 flashes = Dusk-to-Dawn

#### **Operational Mode**

The light has three modes of operation: Always on, Standby Mode and Dusk-to-Dawn mode. These modes can be selected either via the IR remote control or via the GSM module (if fitted).

In Always On mode, the daylight sensor is disabled and the lantern will remain ON.

In Standby mode, the lantern is turned off and the daylight sensor is disabled. This mode does not affect the operation of the GSM module.

In Dusk-to-Dawn, the daylight sensor is enabled.









Always on mode









Standby mode









Dusk-to-Dawn mode



#### **Battery Status (12V System Only)**



This function reads the battery status. The response from the light is:

4 flashes = High Voltage

3 flashes = Good Voltage

2 flashes = Low Voltage

1 flashes = Cut-off Voltage or below

#### **Example Key sequence:**







#### **Error/Acknowledge Indication**

If the key sequence is invalid, or an out of bounds value is attempted to be set, the light flashes 5 times for 1 second. (The command then needs to be sent from the start.)

**Example key sequence:** (Set the intensity level to 5 – undefined.)







The light flashes 5 times for 1 second.

When a key sequence has been entered successfully the light will respond acknowledgement with a 1 second flash.

# **Optional GPS Synchronization**

Avlite has utilized the latest advancements in GPS technology to develop an internal synchronization system that can be incorporated into the lights. Using overhead satellites, multiple obstruction lights set to the same flash pattern will flash in unison.

No additional power supplies, aerials or control systems are required, and with its microprocessor- based system, the GPS option is specifically designed to provide maximum reliability and performance over a wide range of environmental conditions.

### **Operating Principle**

Each light operates independently and requires no operator intervention. A minimum of 4 satellites need to be in view for the built-in GPS receiver to collect time data. At dusk, the light sensor will turn the light on. If time data is available, the light will come on synchronized to every other light with the same selected flash code.

Synchronization is achieved using an internal algorithm based on the highly accurate time base and time data received from the satellites. The satellite data is provided from a number of earth stations using atomic clocks as the time base. Continuous self-checking ensures that the light will continue to run in synchronization.

# **Light Activation**

At power-up the microprocessor checks that the internal GPS module is programmed correctly and is able to provide valid time base and time data.

Once outside with a clear view of the sky, valid data should become available within 20 minutes.

# **Daylight Operation**

During daylight hours, the microprocessor is in idle mode to reduce power consumption. Time data continues to be updated once per second. The microprocessor will automatically exit the idle mode as soon as dark conditions are detected.



# **Dark Operation**

When dark conditions are detected the light:

- Checks for valid time data and is turned on after a delay based on the current time and the length of the selected flash code;
- If valid time data is not detected the light will turn on after approximately 10 seconds.
   This light will not be synchronized.
- If the light turns on unsynchronized it will continually check for valid time data. Once valid data is found the light will automatically synchronize.



Lights will not synchronize if different flash codes are selected.

#### **GPS Power Demand**

The GPS synchronization feature has been designed to function with a very low power demand. Typically, the total 24hr current used by the GPS module is 36mAh. This is approximately equivalent to 8 minutes of solar charging.

# **Optional GSM Monitoring & Control**

The Avlite obstruction light is available with GSM Cell-Phone Monitoring, enabling operators to remotely monitor the status of their installation. The system can also be configured to send out SMS text messages or e-mail alerts to designated operators should alarm conditions be triggered, such as low voltage or light failure.

Please contact Avlite for operational information for GSM Monitoring & Control

# **Troubleshooting**

Problem	Remedy
Light will not activate.	<ul> <li>Ensure proper connectivity with power supply</li> <li>Ensure that the power supply has the right polarity and voltage range</li> <li>Cover the light sensor to force the light ON</li> </ul>



# **Lantern Status**

Lantern Status The AV-OL-FL864-12/UM lanterns are fitted with two status LEDs and provide the operator with an indication of the lantern status


There is one red and one yellow status LED. The red status LED is used to indicate the health of the Lantern's power system. The yellow status LED is used to indicate the operational status of the lantern. These indicator LED's can be viewed at the base of the lens.

Red Status LED	Lantern Status	Lantern	Condition
Steady	Flat Battery cut off is in effect	OFF	Battery voltage is less than 10.0V
Slow	High Voltage	ON	Battery voltage is above 13.5V
Off	Optimal Voltage	ON	Battery Voltage is between 12.5V – 13.5V
1 Quick	OK Voltage	ON	Battery Voltage is between 12.0V – 12.5V
2 Quick	Low Voltage	ON	Battery Voltage is between 11.5V – 12.0V
3 Quick	Poor Voltage	ON	Battery Voltage is between 10.0V – 11.5V
4 Quick	Flat Voltage	ON	Battery voltage is less than 10.0V

Once the Flat Battery cut-off condition is in effect, the lantern will not turn back on until it sees day light and the battery voltage is above 12.5V for at least one minute.

Yellow Status LED	Lantern Status	Lantern	Condition
Off	Daylight, Standby	OFF	Lantern is in Daylight and in Dusk till Dawn mode or in Standby Mode
Quick Flashing 0.15s on, 0.15s off	Day to night transition	OFF	Light is activating and will turn on after detecting 30 seconds of continuous darkness.
2 Quick Flashes every 2s	Night Operation, Not Synchronized	ON	Lantern is in Normal operating condition. It is not connected to any GPS synchronisation
1 Quick Flashes every 2s	Night Operation, Sync in Progress	ON	Lantern is 're-syncing' with GPS. The lantern re-syncs with the GPS every 15 minutes.
Slow Flashing 1.5s on, 1.5s off	Night Operation, Synchronized	ON	Normal operating condition. Lantern is synchronised to GPS-enabled lanterns
2 Quick flashes every 11s	Night Operation, Synchronized	ON	Lantern is a Hard Wire Synchronisation Slave.

If the lantern is not fitted with GPS Synchronization Option, then the following conditions are not possible: 1 Quick Flash, and Slow Flashing.



The LEDs are located on the side of the lantern.

# Certification

Certified to: FAA AC NO: 150/5345-43 H, L-864

FAA Engineering Brief No. 67

DGAC L-864

Transport Canada: CAR, Standard 621; CL-864



# **Avlite Light Warranty V1.2**

### **Activating the Warranty**

Upon purchase, the Avlite Systems warranty must be activated for recognition of future claims. To do this you need to register on-line. Please complete the Online Registration Form at: www.avlite.com

Avlite Systems will repair or replace your lantern in the event of electronic failure for a period of up to three years from the date of purchase. Avlite Systems will repair or replace any ancillary or accessory products in the event of failure for a period of up to one year from the date of purchase, as per the terms & conditions below.

The unit must be returned to Avlite freight prepaid.

### **Warranty Terms**

- 1. Avlite Systems warrants that any Avlite aviation products fitted with telemetry equipment including but not limited to AIS, GSM, GPS or RF ("Telemetry Products") will be free from defective materials and workmanship under normal and intended use, subject to the conditions hereinafter set forth, for a period of twelve (12) months from the date of purchase by the original purchaser.
- 2. Avlite Systems warrants that any rotationally-moulded products ("Roto-moulded Products") and accessory products ("Accessory Products") will be free from defective materials and workmanship under normal and intended use, subject to the conditions hereinafter set forth, for a period of twelve (12) months from the date of purchase by the original purchaser.
- **3.** Avlite Systems warrants that any Avlite aviation products other than the Telemetry Products, Roto-moulded Products and Accessory Products ("Avlite Products") will be free from defective materials and workmanship under normal and intended use, subject to the conditions hereinafter set forth, for a period of four (4) years from the date of purchase by the original purchaser.
- 4. Avlite Systems will repair or replace, at Avlite's sole discretion, any Telemetry Products, Roto-moulded Products, Accessory Products or Avlite Products found to be defective in material and workmanship in the relevant warranty period so long as the Warranty Conditions (set out below) are satisfied.
- 5. If any Telemetry Products or Avlite Products are fitted with a rechargeable battery, Avlite Systems warrants the battery will be free from defect for a period of one (1) year when used within original manufacturer's specifications and instructions.

# **Warranty Conditions**

This Warranty is subject to the following conditions and limitations;

**1.** The warranty is applicable to lanterns manufactured from 1/1/2009.

- 2. The warranty is void and inapplicable if:
  - a. the product has been used or handled other than in accordance with the instructions in the owner's manual and any other information or instructions provided to the customer by Avlite;
  - b. the product has been deliberately abused, or misused, damaged by accident or neglect or in being transported; or
  - c. the defect is due to the product being repaired or tampered with by anyone other than Avlite or authorized Avlite repair personnel.
- **3.** The customer must give Avlite Systems notice of any defect with the product within 30 days of the customer becoming aware of the defect.
- **4.** Rechargeable batteries have a limited number of charge cycles and may eventually need to be replaced. Typical battery replacement period is 3-4 years. Long term exposure to high temperatures will shorten the battery life. Batteries used or stored in a manner inconsistent with the manufacturer's specifications and instructions shall not be covered by this warranty.
- **5.** No modifications to the original specifications determined by Avlite shall be made without written approval of Avlite Systems.
- **6.** Avlite lights can be fitted with 3rd party power supplies and accessories but are covered by the 3rd party warranty terms and conditions.
- 7. The product must be packed and returned to Avlite Systems by the customer at his or her sole expense. Avlite Systems will pay return freight of its choice. A returned product must be accompanied by a written description of the defect and a photocopy of the original purchase receipt. This receipt must clearly list model and serial number, the date of purchase, the name and address of the purchaser and authorized dealer and the price paid by the purchaser. On receipt of the product, Avlite Systems will assess the product and advise the customer as to whether the claimed defect is covered by this warranty.
- **8.** Avlite Systems reserves the right to modify the design of any product without obligation to purchasers of previously manufactured products and to change the prices or specifications of any product without notice or obligation to any person.
- **9.** Input voltage shall not exceed those recommended for the product.
- **10.** Warranty does not cover damage caused by the incorrect replacement of battery in solar lantern models.
- **11.** This warranty does not cover any damage or defect caused to any product as a result of water flooding or any other acts of nature.
- **12.** There are no representations or warranties of any kind by Avlite or any other person who is an agent, employee, or other representative or affiliate of Avlite, express or implied, with respect to condition of performance of any product, their merchantability, or fitness for a particular purpose, or with respect to any other matter relating to any products.



#### **Limitation of Liability**

To the extent permitted by acts and regulations applicable in the country of manufacture, the liability of Avlite Systems under this Warranty will be, at the option of Avlite Systems, limited to either the replacement or repair of any defective product covered by this Warranty. Avlite Systems will not be liable to Buyer for consequential damages resulting from any defect or deficiencies in accepted items.

# **Limited to Original Purchaser**

This Warranty is for the sole benefit of the original purchaser of the covered product and shall not extend to any subsequent purchaser of the product.

#### Miscellaneous

Apart from the specific warranties provided under this warranty, all other express or implied warranties relating to the above product is hereby excluded to the fullest extent allowable under law. The warranty does not extend to any lost profits, loss of good will or any indirect, incidental or consequential costs or damages or losses incurred by the purchaser as a result of any defect with the covered product.

#### Warrantor

Avlite Systems has authorized distribution in many countries of the world. In each country, the authorized importing distributor has accepted the responsibility for warranty of products sold by distributor. Warranty service should normally be obtained from the importing distributor from whom you purchased your product. In the event of service required beyond the capability of the importer, Avlite Systems will fulfil the conditions of the warranty. Such product must be returned at the owner's expense to the Avlite Systems factory, together with a photocopy of the bill of sale for that product, a detailed description of the problem, and any information necessary for return shipment.

Information in this manual is subject to change without notice and does not represent a commitment on the part of the vendor. Sealite products are subject to certain Australian and worldwide patent application

# **Other Avlite Products Available**



Solar Aviation Lighting



**Obstruction Lighting** 



Heliport Lighting



Monitoring and Control

**Australia Tel.** +61 (0)3 5977 6128

**USA Tel.** +1 (603) 737 1310

**United Kingdom Tel.** +44 (0) 1502 588026



We believe technology improves navigation™

Learn more www.avlite.com info@avlite.com

